INTERNATIONAL STANDARD

ISO 16065-2

First edition 2007-02-01

Pulps — Determination of fibre length by automated optical analysis —

Part 2:

Unpolarized light method

Pâtes — Détermination de la longueur de fibre par analyse optique automatisée —

Partie 2: Méthode de la lumière non polarisée

Circh to vien

STANDARDSISO.



PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

STANDARDSISO.COM. Click to View the full Park of ISO 16065 2:2007

© ISO 2007

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office Case postale 56 • CH-1211 Geneva 20 Tel. + 41 22 749 01 11 Fax + 41 22 749 09 47 E-mail copyright@iso.org Web www.iso.org

Published in Switzerland

Page

0011		i age		
Forev	word	iv		
1	Scope	1		
2	Normative references			
3	Terms and definitions	1		
4	Principle	2		
5	Apparatus and auxiliary materials	2		
6	Sampling	3		
7	Preparation of sample	3		
8	Procedure	4		
9	Calculation and expression of results	5		
10	Test report	7		
Bibliography				
	Normative references 1 Terms and definitions 1 Principle 2 Apparatus and auxiliary materials 2 Sampling 3 Preparation of sample 3 Procedure 4 Calculation and expression of results 5 O Test report 7 Sibliography 9			

Contents

© ISO 2007 – All rights reserved iii

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Rart 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 16065-2 was prepared by Technical Committee ISO/TC 6, Paper, board and pulps, Subcommittee SC 5, Test methods and quality specifications for pulps.

eral tit, click to view the standard second control of the second ISO 16065 consists of the following parts, under the general title Pulps — Determination of fibre length by automated optical analysis:

- Part 1: Polarized light method
- Part 2: Unpolarized light method

Pulps — Determination of fibre length by automated optical analysis —

Part 2:

Unpolarized light method

1 Scope

This part of ISO 16065 specifies a method for determining fibre length by automated optical analysis, using unpolarized light.

The method is applicable to all kinds of pulp. However, fibrous particles shorter than 0,2 mm are not regarded as fibres for the purposes of this part of ISO 16065 and therefore are not included in the results.

NOTE ISO 16065-1 deals with the determination of fibre length using polarized light.

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 638, Pulps — Determination of dry matter content

ISO 4119, Pulps — Determination of stock concentration

ISO 5263-1, Pulps — Laboratory wet disintegration — Part 1: Disintegration of chemical pulps

ISO 5263-2, Pulps — Laboratory wet disintegration — Part 2: Disintegration of mechanical pulps at 20 °C

ISO 5263-3, Pulps — Laboratory wet disintegration — Part 3: Disintegration of mechanical pulps at ≥ 85 °C

ISO 7213, Pulps — Sampling for testing

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

3 1

unpolarized light

light composed of light waves whose planes of vibration are randomly oriented

3.2

mean length

L

total length of all fibres counted divided by the number of fibres

See Equation 3.

3.3

length-weighted mean length

 L_1

average of the length-weighted fibre-length distribution

See Equation 4.

3.4

length-length-weighted mean length

L...

average of the mass-weighted fibre-length distribution

See Equation 5.

NOTE Length-length-weighted mean length was formerly called mass-weighted mean length.

4 Principle

Fibres suspended in water are routed through a measuring cell, where the lengths of individual fibres are measured. A suitable unpolarized light source is used to create the high-contrast image between fibres and the background. The numerical and weighted average fibre lengths and fibre-length distributions of pulp are calculated.

5 Apparatus and auxiliary materials

Ordinary laboratory equipment and the following are required.

- **5.1 Fibre-length analyser**, consisting of a measurement section and a sample transport system. The measurement section consists of a measuring cell, through which fibres in water are drawn. There is a uniform unpolarized light source on one side of the cell and a sensitive detector [for example, a charge coupled device (CCD) camera] on the same or on the opposite side of the measuring cell. The flow orientates the fibres into a focal depth no thicker than 0,5 mm normal to the sample flow. The sample flow may be stopped when the CCD camera takes a picture. The detector indicates the fibre length from the image of the fibre. The analyser shall have a resolution equal to or better than 100 μm over the range 0 mm to 7 mm, and an accuracy of at least 0,01 mm.
- **5.1.1 Measuring system**, constructed so that air bubbles and non-fibrous particles greater than 0,2 mm do not have any effect on the results.
- **5.2 Disintegrator**, as described in ISO 5263-1, ISO 5263-2 or ISO 5263-3.
- **5.3 Verification fibres**, made of rayon with suggested lengths of about 0,5 mm, 3,0 mm and 7,0 mm, with an accuracy of 0,01 mm. The fibres shall be provided by the producer of the analyser, together with statistical data showing the mean length and the length distribution of each type of verification fibre.
- **5.4** Reference pulp¹⁾, a commercial reference pulp is available. A quantity of pulp for which the length-weighted fibre length has previously been determined using this part of ISO 16065.

NOTE In-house reference pulp may also be used.

¹⁾ Reference pulp is available, for example, from the device supplier or the National Institute of Science & Technology, Gaithersburg, MD, USA (NIST). The reference pulp is provided in sheet form. This information is given for the convenience of users of this document and does not constitute an endorsement by ISO of this product.

5.5 Dilution water, free of non-fibrous material and air bubbles greater than $5 \mu m$, and having an evaporation residue less than 50 mg/l. Non-fibrous particles can be removed from water by filtering (pore size $5 \mu m$) and air bubbles can be removed by the application of heat, vacuum and/or a settling time.

6 Sampling

If the test is being made to evaluate a pulp lot, the sample shall be selected in accordance with ISO 7213. If the test is made on another type of sample, report the source of the sample and, if possible, the sampling procedure used.

From the sample received, select specimens so that they are representative of the whole sample

7 Preparation of sample

7.1 Disintegration

If the sample is in dried form, determine the dry matter content in accordance with ISO 638. If the sample is in slush form, determine the stock concentration in accordance with ISO 4119.

NOTE It is preferable to measure never-dried pulps without disintegration, because excessive disintegration may generate fines and reduce fibre length in some pulps.

7.1.1 Dry pulp samples

If the sample is in the dried form, tear the specimens into pieces before soaking. Tear the pieces evenly throughout the thickness of the pulp sheet. By visual assessment make sure that the fibres are properly separated. Do not cut the sample, as this will cause fibre shortening. Soak the specimen according to the relevant part of ISO 5263.

Disintegrate the specimens, if required (see the note in 7.1), using the apparatus described in the relevant part of ISO 5263. If the disintegrator described in ISO 5263 is used, the soaking time, oven-dry mass of the pulp, the amount of water to be used in the disintegration and the number of revolutions are specified in the relevant part of ISO 5263. Use the dilution water (5.5). For the removal of latency from mechanical pulps, follow the recommendations given in ISO 5263-3.

For pulps containing fibre bundles [e.g. Canadian high-freeness thermo-mechanical pulp (TMP)] and chemithermo-mechanical pulp (CTMP), it may be difficult to measure the fibre length, since the fibre bundles may plug the flow cell. If plugging occurs, then screening is recommended to remove the fibre bundles. Screening may be the results since it will remove fibre bundles, which preferentially contain longer fibres. After screening, make sure that the fibres are completely separated and fully dispersed.

WARNING— Very long fibres (e.g. hemp, cotton, flax) may require some special sample preparation techniques if they are so long that part of the fibres are outside the measuring window, or if they cause blocking of the fibre-orientating cell.

7.1.2 Wet pulp samples

Dilute to the consistency required for accurate measurements following the instructions in 7.2.

Wet pulp samples may contain fibre bundles and, if plugging occurs, follow the instructions given in 7.1.1.

© ISO 2007 – All rights reserved

7.2 Stock dilution

Stir and take an aliquot from the uniformly dispersed specimen from 7.1. Dilute by serial dilution, to the concentration recommended by the instrument's manufacturer, or to that determined by tests over the concentration range. When taking the sample, the diluted suspension must be agitated continuously. Do not stir with a rotary movement because the sample dilution will not be homogenous.

NOTE Pouring the test sample back and forth will achieve the desired agitation.

The recommended mass fraction to be used in this method is 0,010 % to 0,025 % for softwood pulp, and 0,004 % to 0,010 % for hardwood pulp. Mixed stocks should be treated as hardwood pulps. In order to get accurate measurements, the suspension must be diluted using dilution water (5.5).

8 Procedure

8.1 Measurement procedure

The suspension shall be agitated continuously to ensure complete mixing. Take at least a 50 ml test portion from the continuously agitated dilute sample. Carry out the test according to the instructions of the instrument manufacturer. The minimum number of fibres to measure shall be that at which the mean length reaches a steady state variance of 0,01 mm (i.e. measuring more fibres does not change the mean-length value by more than 0,01 mm). If the apparatus does not continuously provide fibre-length values during a test, a minimum of 5 000 fibres shall be measured.

8.2 Verification procedure using verification fibres

8.2.1 General

Check the performance of the analyser regularly and always after cleaning. A verification procedure shall include a calibration check every week and a performance check every month. If the analyser is used infrequently, check the calibration prior to each use:

8.2.2 Calibration check with verification fibres

Run a calibration check using the verification fibres (5.3).

In the check, record data for at least 5 000 fibres or until a 1 % coefficient of variation (CV) level on the mean-length value is achieved. Prepare a new portion of calibration fibres for each check.

Use only verification fibres that have been dispersed on the same day as the calibration check is made, since rayon fibres tend to floculate.

Stir the fibre suspension, when taking an aliquot from the suspension. Make sure that the fibres do not form flocks. If they do, the calibration check cannot be carried out.

It is very important that the pulp suspension is continuously agitated, to prevent fibres from settling.

Compare the fibre-length data obtained with the data provided for the verification fibres by the manufacturer. If the results of the calibration check lie outside the tolerance limits given, clean the system and run a new calibration check. If the new data still lie outside the tolerance limits, follow the recommendations given by the manufacturer of the analyser.

8.2.3 Performance check using reference pulp

The calibration check is not sufficient to give a true picture of the functioning of the analyser. Check the performance of the analyser every month using fibres from a reference pulp (5.4).

Prepare and analyse the reference-pulp sample following the procedure described in this part of ISO 16065. Compare the data achieved with the specifications of the supplier of the reference pulp, or with the previous performance checks if an in-house reference pulp is used. The tolerance limit for a length-weighted fibre length of chemical pulps is \pm 1,5 %.

If the check data lie outside the tolerances given, clean the analyser and run a new check. If the data are still outside the tolerances given, contact the manufacturer of the analyser for service.

Make sure that reference material is available for future performance checks. If not, select a suitable material for use as a reference pulp and determine its length-weighted fibre length using this part of ISO 16065 to provide a basis for future comparisons.

9 Calculation and expression of results

9.1 Method of calculation

The number of fibres (n_i) in each class of length l_i is counted.

For each class, the percentage frequency by number, f_i , is calculated using the equation

$$f_i = \frac{n_i}{\sum n_i} \times 100 \tag{1}$$

and the percentage length-weighted frequency, f'_i , is calculated using the equation

$$f'_i = \frac{n_i l_i}{\sum n_i l_i} \times 100 \tag{2}$$

where

 n_i is the number of fibres in the *i*th class;

 l_i is the central length of the *i*th class, in millimetres;

 $\sum n_i$ is the total number of fibres in all classes;

 $\sum n_i l_i$ is the sum of the products, $n_i \times l_i$, for all classes.

9.2 Characteristic distribution values

9.2.1 Lengths

The following expressions are used for calculating the required quantities and the mean fibre length (other quantities may also be calculated for particular purposes):

a) the mean length of the fibres:

$$L = \frac{\sum n_i l_i}{\sum n_i} \tag{3}$$

NOTE 1 The numerical mean fibre length is not always the most meaningful indicator of the fibre length, because the effect of short fibres is emphasised. A better expression is often the length-weighted mean fibre length.

© ISO 2007 – All rights reserved

the length-weighted mean length of the fibres (L_i) :

$$L_{l} = \frac{\sum n_{i} l_{i}^{2}}{\sum n_{i} l_{i}} \tag{4}$$

the length-length-weighted mean length of the fibres (L_w) :

$$L_{W} = \frac{\sum n_{i} l_{i}^{3}}{\sum n_{i} l_{i}^{2}} \tag{5}$$

NOTE 2 In the interpretation of the length-weighted mean length, it is assumed that all fibres have identical coarseness. In the interpretation of the length-length-weighted mean length, it is assumed that fibre coarseness is proportional to the length. This proportionality does not hold for mechanical pulps and pulp mixtures.

length. This proportionality does not hold for mechanical pulps and pulp mixtures.

9.2.2 Coefficient of variation

Calculate the coefficient of variation (%) from the frequency distribution using the equation

$$CV = \frac{s}{L} \times 100$$

where the standard deviation s in millimetres, is given by the equation

where the standard deviation s, in millimetres, is given by the equation

contact the coefficient of variation (%) from the frequency distribution using the equation
$$CV = \frac{s}{L} \times 100$$
re the standard deviation s , in millimetres, is given by the equation
$$s = \left(\frac{\sum (l_i - L)^2 n_i}{\sum n_i}\right)^{1/2}$$
(7)

we were if the values L and L are calculated the coefficient of variation (%) may be calculated using the

However, if the values L and L_i are calculated, the coefficient of variation (%) may be calculated using the equation

rever, if the values
$$L$$
 and L_l are calculated, the coefficient of variation (%) may be calculated using the ation
$$CV = 100 \left(\frac{L_l}{L} - 1 \right)^{1/2}$$
(8)

Expression of the frequency distribution

9.2.3 Expression of the frequency distribution

If a length-distribution graph is required, express it

- by a frequency diagram representing the number and/or the percentage of the fibres in each length interval employed, expressed as a function of the length, and/or
- by a cumulative frequency diagram indicating the percentage as a function of fibres greater than a given length, expressed as a function of the length.

9.3 **Precision**

Repeatability

Five samples, two softwoods, one hardwood, one TMP sample and one pressurized groundwood (PGW) pulp sample were tested with four different manufacturers' instruments in different laboratories according to this part of ISO 16065. The samples were not screened. The pooled repeatability was determined and the results were as given in Table 1.

Table 1 — Repeatability for determination of fibre length

Sample	Length-weighted mean length, ${\cal L}_l$	Coefficient of variation
Sample	mm	%
Softwood, unrefined	2,07	1,3
Softwood, refined	2,10	4,3
Hardwood, unrefined	0,75	0,7
Thermomechanical pulp (TMP) (CSF = 134)	1,60	2,3
Pressurized groundwood (PGW) pulp (CSF = 65)	0,88	A®1
CSF: Canadian Standard Freeness.		

9.3.2 Reproducibility

Five samples, two softwoods, one hardwood, one TMP sample and one PSW sample were tested with four different manufacturers' instruments in different laboratories according to this part of ISO 16065. The samples were not screened. The results were as given in Table 2.

Table 2 — Reproducibility for determination of fibre length

Sample	Length-weighted mean length, L_l	Coefficient of variation		
Jampie	MU.	%		
Softwood, unrefined	2,07	5,2		
Softwood, refined	2,10	5,3		
Hardwood, unrefined	0,75	8,2		
Thermomechanical pulp (TMP) (CSF = 134)	1,60	16,7		
Pressurized groundwood pulp (PGW) (CSF = 65)	0,88	19,7		
CSF: Canadian Standard Freeness				

9.3.3 Comparison of results between instruments using polarized and unpolarized light

The same samples as mentioned above (repeatability and reproducibility tests) were also analysed with instruments using polarized light. The correlation between instruments using polarized and unpolarized light was 96,2 %:

10 Test report

The test report shall give the following information:

- a) a reference to this part of ISO 16065;
- b) the date and place of testing;
- c) all information for complete identification of the sample;
- d) the type of instrument used;

© ISO 2007 – All rights reserved